

## 10.0 (US Version)



Hardware Plattform	G13
Update to Firmware	7.09A.0.47
Download	<p><a href="https://www.stepoverinfo.net/download.php?file=g13_US_Update-7.09A.0.47.zip">https://www.stepoverinfo.net/download.php?file=g13_US_Update-7.09A.0.47.zip</a></p> <p>Steps:</p> <ul style="list-style-type: none"><li>• download the Firmware Updater</li><li>• if the device has Firmware 5.x or 6.x you need to start the <b>Update_from_Firmware_5or6.bat</b></li><li>• if the device already has Firmware Version 7 you need to start the <b>Update_from_Firmware_7.bat</b></li><li>• after the Update there should be the message that Update was successful and the Pad will show Firmware 7.08E in the bootscreen</li></ul> <p>In case of Problems:</p> <ul style="list-style-type: none"><li>• in case the update fails try to repeat the update</li><li>• if the pad is without firmware (display stays black and the LED blinks green), you need to run <b>Update_from_Bootloader(recovery).bat</b></li><li>• if you have a pad which is reebooting all the time, use the <b>for_rebooting_device.bat</b></li><li>• in case the update fails with the error which include "<b>crypt wrong?</b>" you are using the wrong updater Version, contact our support (<a href="mailto:service@stepover.de">service@stepover.de</a>) for help</li></ul>