

10.0



| | |
|--------------------|--|
| Hardware Plattform | G13 |
| Update to Firmware | 7.09E.0.47 |
| Download | <p>https://www.stepoverinfo.net/download.php?file=g13_Update-7.09E.0.47.zip</p> <p>Steps:</p> <ul style="list-style-type: none"> • download the Firmware Updater • if the device has Firmware 5.x or 6.x you need to start the Update_from_Firmware_5or6.bat • if the device already has Firmware Version 7 you need to start the Update_from_Firmware_7.bat • after the Update there should be the message that Update was successful and the Pad will show Firmware 7.08E in the bootscreen <p>In case of Problems:</p> <ul style="list-style-type: none"> • in case the update fails try to repeat the update • if the pad is without firmware (display stays black and the LED blinks green), you need to run Update_from_Bootloader(recovery).bat • if you have a pad which is rebooting all the time, use the for_rebooting_device.bat • in case the update fails with the error which include "crypt wrong?" you are using the wrong updater Version, contact our support (service@stepover.de) for help |